To install new firmware:

1. Copy the supplied binary file on to a memory stick using your PC.
2. Plug the memory stick in to the USB port.
3. Power up the machine while holding down the RED and UP buttons at the same time - the Bootloader software should start.
4. When requested enter the password (ZORIN), using the UP, DOWN, LEFT and RIGHT buttons.
5. Select the file from those available by using the UP and DOWN buttons.
6. Press the GREEN button to install the file.
7. Wait for the download to complete.
8. Turn the machine off, then on.

NOTE: ! Software Updated !

If the following message is displayed;

! Software Updated ! Enter diagnostics and verify configuration.

1. Restart the machine
2. Enter Diagnostics.
     o Pressing the square (**RED**) button while the logo is displayed.
3. Select an access level (password or square (**RED**) button).
4. Exit Diagnostics by pressing the square (**RED**) button until the Project screen is displayed.
5. The update has now been verified.